
1. Press and hold the "X" button on your Yealink phone for 5-10 seconds:



2. A message on the screen will display, "Reboot the Phone?" Select OK, and the phone will reboot.

